


# Yealink T46G

Quick Reference guide May 2017



1	LCD Screen, Shows Call Information, Missed calls, Voicemail, Time and Date and DND.	
2	Power and Message waiting indicator.	
3	BLF, Park and Feature Keys.	
4	Mute	Mutes the microphone so the other party cannot hear you.
	Headset	Switches between Handset and Headset use.
5	Hold	Used to place a call on hold.
	Message	Used to collect your messages.
	Transfer	Used to transfer calls to another extn.
	Redial Keys	Redials a previously dialed number.
6	Speakerphone Key, Toggles hands free operation.	
7	Volume Key, Adjusts handset, headset, speaker and ringer volume.	
8	Keypad, Provides digits, letters and special characters in context-sensitive applications.	
9	$( \cdot ) ( \cdot ) ( \cdot ) ( \cdot )$ Menu navigation keys	
	ОК	OK key
	×	Cancel key.
10	Context sensitive keys.	



The Hall Farm Business Centre, Berry Lane, Chorleywood, Hertfordshire WD3 5EX Tel: 01923 287700 Fax: 01923 287722 Email: info@splicecom.com Website: www.splicecom.com

This page is left intentionally blank

This page is left intentionally blank





#### Changing your Greeting



# **\***.

#### Changing your daily Greeting







#### Changing your permanent Greeting







# Voicemail (cont)

#### Changing your Daily and Permanent Voicemail Greetings

If you have voicemail enabled you can record two voicemail greetings. The first is a daily greeting that you would normally update on a daily basis, typically giving the date and your whereabouts/availability. The second is a permanent greeting that can be used on any day. If you choose to record a permanent greeting your daily greeting will be deleted at midnight and the permanent greeting will then be used until you record a new daily greeting.

Press the Messages button.

Whilst listening to the first prompt press the \* key you will hear a list of options.

#### Changing your daily Greeting

To change your daily greeting select option 2

You will then be prompted to record your new Daily Greeting. Press hash (#) when finished.

Your new Daily Greeting will be played back to you, if you are happy with your greeting, replace your handset, press the Speaker button or End Call button. You can also select 6 and then option 2 for a daily greeting

#### Changing your permanent Greeting

To change your permanent greeting select option 6 followed by option 3

You will then be prompted to record your new Daily Greeting. Press hash (#) when finished.

Your new permanent greeting will be played back to you, if you are happy with your greeting, replace your handset, press the Speaker button or End Call button. You can also select 6 and then option 2 for a daily greeting

For further details on the other voicemail features please Refer to your maintainer.

# Making an Internal Call





# Making an Internal Call

Dial the extension number via the alpha-numeric keypad



Press **Send**, hash, OK key, or lift your handset to make the call.

The Call Status screen will display whom you are ringing and your details

#### OR

Lift your handset or press the Speaker button Dial the extension via the alpha-numeric keypad

#### OR



Directory

Press the Directory Key

Press the key on the keypad that displays the first letter of the User's name, keep entering the characters to refine the search then.

Find the user required using the Navigation Keys

Select the user required and then press the OK Key to call that user.

(Note: If the extension you are ringing is busy or not answered within 20 seconds (default) you will be passed to voicemail, if enabled.)





#### Making an External Call
















# Making an External Call

Dial the external number via the alpha-numeric keypad. (Your System Administrator will inform you if a prefix is required.)

Press Send, hash, OK key, or lift your handset to make the call.

Lift your handset or press the Speaker Key.

The Call Status screen will display whom you are ringing and your details.

Press the key on the keypad that displays the first letter of the User's name, keep entering the characters to

Find the user required using the Navigation Keys

### OR




Dial the external number via the alpha-numeric keypad. (Your System Administrator will inform you if a prefix is

required.)

Press the Directory Key

refine the search then.





Made

Received

And Missed

Find the call required using the Navigation Keys

then press the OK Key to make a call to that number

#### Leaving a Message for a Colleague



## Accessing Your Own Messages





Press the Messages Key to listen to your messages, any new messages will be played automatically.

If the extension you are ringing is busy or is not answered

Replace your handset (if you are using the handset), or

press the Speaker button (if you are using hands free)

The message waiting indicator on the T41P will flash to

see a cassette icon appear on the main screen.

let you know that you have a new voicemail, you will also

vou will be transferred to voicemail (if enabled) and

Whilst the message is playing you can use the keypad to do the following: -



Press 1 to play help Press 2 to skip forward 2 seconds Press 3 to delete the message Press 4 to play the previous message Press 5 to forward the message Press 6 to play the next message Press 7 to save the message Press 8 to skip backwards 2 seconds Press 9 to play the callers number Press \* for configuration options Press 0 to return the call\*

Voicemail

Leaving a Message for a Colleague

played your colleague's greeting.

Accessing Your Own Messages

Leave your message.


\*Voicemail forwarding must be enabled for this to work, please see your reseller for details.



# Yealink T46G



#### **Redialing a Number**



#### To Call a Previous Caller





## To Delete a Call Entry





Back

## Redialing a Number

To redial a number, press the redial key, you will get a list of made of made call displayed on the main screen.

Use the navigation keys to select the number you wish to redial and then press the Send button.

# To Call a Previous Caller Back

Press the History button.

Use the Navigation keys to select the number you wish to call back and then press the Send button.

# To Delete a Call Entry

Press the History button.

Use the navigation keys to select the call you wish to delete, then press the delete button.

Press the back button to return to the main screen.






# Ending a Call



## Placing a Call on Hold



#### Announced Transfer





# Answering a Call

The main screen will show the details of the caller, Lift the handset or press the Speaker, Answer or OK buttons to answer the call.

# OR

If you do not wish to answer the call press the reject button and the call will be passed to your Forward on Busy number (if set), or to voicemail (if enabled), or cancelled. (If your phone is busy or not answered within 20 seconds (default) the caller will be passed to voicemail, if enabled.)

# Ending a Call

Replace your handset (if you are using the handset), or press the Speaker button (if you are using hands free)

# Placing a Call on Hold

Press the Hold Key

To retrieve the call press the resume button

# Transferring a Call Announced Transfer

Place the call on hold using the Tran Key

Dial the internal or external number and wait for the call to be answered and then announce the intended transfer.

To transfer the original call, replace your handset (if you are using the handset) or press the Speaker button (if you are using hands free) or press the Tran button.

## O

To return to the original call, press the Cancel and then the Resume Key, or wait for the destination to hang up and then press the Resume key


Yealink T46G Quick Reference Guide Version 1/0517/1



# **Yealink T46G**



Blind Transfer



Transfer to colleague's voicemail





Tran





# Transferring a Call (cont)

Blind Transfer (un-announced transfer)

Place the call on hold using the Tran Key

Dial the internal or external number

To complete the transfer, replace your handset (if you are using the handset) or press the Speaker button (if you are using hands free) or press the Tran key and replace the handset

Transferring a Call Directly to a Colleague's voicemail

Place the call on hold using the Tran Key

Dial the internal number prefixed with a # i.e. #200 if you wanted to transfer the call to ext 200's voicemail.

Press the Tran key again to complete the transfer

# Parking and Picking up a Call

This facility allows a call to be held on the system and picked up by any extension. Once on a call press one of 4 Park keys to park the call

The caller's details will be displayed against the relevant Park Slot and the led indicator will flash red showing that there is a parked call waiting to be picked up.

Identify the person you wish to pickup and press the button next the relevant park slot to pick up the call.

#### Conferencing a call









## To conference a call press the Conference button, enter the ext. you wish to conference.

Conferencing a Call

2



You can swap between calls by pressing the Swap button, or to conference all parties press the Conference button again.